andis®

MODEL AGRC CLIPPER
120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1		Lower Housing	
1a	63918	Lower Housing (Metallic Blue)	1
1b	65188	Lower Housing (Metallic Green)	1
2		Upper Housing	
2a	63953	Upper Housing (Metallic Blue)	1
2b	65198	Upper Housing (Metallic Green)	1
3		Drive Cap	
3a	22449	Drive Cap (Metallic Blue)	1
3b	65199	Drive Cap (Metallic Green)	1
4	64902	Switch Button	1
5	64794	Switch Button Lock	1
6	64788	Switch Button Retainer	1
7	64527	Lock Ring	1
8	64508	Motor Battery Contacts	2
9	64944	Rear Motor Frame	1
10	65013	Front Motor Frame	1
11	21067	Small Bearing Mounting Ring	1
12	64507	Switch	1
13	57993	Screw, 5-18 x 0.375	6
14	64503	Copper Brush with Shunt	2
15	65806	Brush Spring	2
16	65805	Brush Retainer Clip	2
17	64514	Motor Frame Clip	2
18	64726	Armature Assembly	1
19	27251	Cam Assembly	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
20	64860	Magnetized Field Assembly	1
21	15766	Screw, 4-40 x 7/32	2
22	22319	Blade Drive Assembly	1
23	21068	Large Bearing Mounting Ring	1
24	64027	Blade Guide	1
25	64013	Tension Spring	1
26	64139	Blade Screw	2
27	64003	Blade Bracket	1
28	64784	O-Ring	1
29	64535	Lock Keeper	1
30	64537	Blade Lock	1
31	27861	Screw, Blade Hinge	2
32	S64608	Hinge Assembly	1
33	64606	Housing Screw	4
34	63075	Corded Adaptor	1
35	64754	Foam Pad	1
36	64916	Oil Seal	1
37	64526	Positive Lead Wire (Not shown)	1

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.